

INSTALLATION OF FOAM BRUSHES

1. Remove the old brushes.
2. Wrap the new brushes around the wheel tube.
3. Snap the tabs with the holes over the corresponding buttons found on the opposite end of the plastic brush grid. Make sure that they fit snugly. Repeat this process with all of the tabs and buttons.

