

INSTALLATION OF SUPER RUBBER BRUSHES

1. Turn the unit upside down. You may want to do this on a soft surface so as not to scratch the body of your machine.
2. Wrap the new rubber brush around the wheel tube, making sure that the long rubber flap extensions are facing outward from the wheel tube.
3. While squeezing together the brush assembly ends, align the individual tubular hinges to form one long hinge and insert the metal rod through the hinge. You may find it easier to insert the metal rod if a small amount of lubricant (such as petroleum jelly) is used.
4. Make certain that the metal rod is completely inserted through the width of the rubber brush.
5. Congratulations! You have successfully installed your new Super Rubber Brush Assembly.



Figure 1



Figure 2



Figure 3



Figure 4